Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70 Казахстан +7(7172)727-132 Киргизия +996(312)96-26-47

https://tigercnc.nt-rt.ru/ || tcn@nt-rt.ru

BS series semi-universal dividing head

Features:
Semi-Universal Dividing Head is a simple Index Center and can be used for direct and indirect dividing.Complete the gear,face,flute processing and no need accessories,but the whole construction is the same as universal type.The 24 quick-dividing holes can complete BS-2A 2,3,4,6,8,12,24 division indexding.Attaches 3dividing plate along with the dividing head indirect dividing in any division indexding 2-50.51-380.



SEMI-UNVERSAL INDEX CENTER B&S TYPE NO.0,NO.1(HEAD-STOCK)

Unit:mm/in

Model	A	B	H	h	a	b	g	Taper of center	Diameter ofSpindle hole	N.W.(kg)
BS-0	193	140	173	100	166	90	16	MT2	18	23.8
	7.59	5.51	6.81	3.93	6.53	3.54	0.63	B&S NO.7		
BS-1	242	168	220	128	206	113	16	MT3	20	35.8
	9.52	6.61	8.66	5.04	8.11	4.45	0.63	B&S NO.9		

STANDARD ACCESSORIES
Dividing plate A.B.C.
Numbers of holes of dividing plate
(worm gear reduction ratio 1:40)

Unit:mm

Numbers of hole	PlateA	15	16	17	18	19	20
	PlateB	21	23	27	29	31	33
	PlateC	37	39	41	43	47	49

OPTIONAL ACCESSORY
3-jaw Chuck
4" or5" 3-jaw Chuck for BS-0
5" or6" 3-jaw Chuck for BS-1
6" or7" 8" 3-jaw Chuck for BS-2

SEMI-UNVERSAL INDEX CENTER B&S TYPE NO.0,NO.1(HEAD-STOCK)

Unit:mm/in

Model	A1	B1	H1	h	a1	b1	g1	N.W.(kg)	Mueasurement m 3
BS-0	175	87	107	100	130	92	16	Packed with the Dividing Head	
	6.89	3.42	4.21	3.93	5.12	3.62	0.63		
BS-1	183	87	137	128	158	110	16	Packed with the Dividing Head	
	7.20	3.42	5.39	5.04	6.22	4.33	0.63		